


# STEALTH


## PLACESAVER™ REUSABLE BRACKETS

## PLACE SAVER

### PRE-INSTALL BRACKET



The PlaceSaver™ mounts over back box to ensure proper rough opening



After wallboard is in place, remove PlaceSaver™ and install speaker

PlaceSavers™ are for temporary use in new construction. The greatest exposure to damage occurs from the time the Stealth Acoustics speaker panels are first mounted to the structural framing and when the taping begins. PlaceSavers™ keep this exposure to a minimum by reducing the speaker panels exposure on the construction site.

Reusable PlaceSavers™ are constructed from ABS plastic and sized slightly larger than the speaker panel

it is reserving space for. This ensures that no matter how tight the drywall is hung to the PlaceSaver™, the speaker panel will easily drop into place when the PlaceSaver™ is removed.

PlaceSavers™ should be installed at the pre-wire stage and replaced with the speaker panel just before drywall seam finishing begins.

PlaceSavers™ are packaged 6 per carton and come with mounting screws. PlaceSavers™ are re-usable.

Model	Fits Speakers
PS-30	LR430, LR30W, LRX-85-LF
PS-24	LR224, LR224S, LR324, LR24W
PS-16	LR116
PS-12	LR112, LR6G, LRX-85-HM