

DENON®

DENON HOME SUBWOOFER


WIRELESS SUBWOOFER



QUICK START GUIDE

BEFORE YOU BEGIN

The Denon Home Subwoofer is designed to be connected to Denon Home speakers and sound bars.




Make sure you have the following items in working order:



Wi-Fi router and
Internet connection




Apple iOS, Android or Kindle
mobile device connected to
your network



Other
Denon Home speakers
and sound bar


STEP 1: UNPACK

Remove the subwoofer and power cord from the box.




STEP 2: PLACE

Place the Denon Home Subwoofer in a convenient location in the same room as the other Denon Home speaker you wish to group the subwoofer with.




Denon Home sound bar + Denon Home Subwoofer



Denon Home speaker + Denon Home Subwoofer


STEP 3: CONNECT

Connect the power cord to the Denon Home Subwoofer and a wall outlet.



OPTIONAL

If you are connecting the Denon Home Subwoofer to a wired network, connect an Ethernet cable (not included) between the Denon Home Subwoofer and your router. Do not connect the Ethernet cable if you are connecting your Denon Home Subwoofer to a wireless network.




STEP 4: CONTROL



- 1 Download the HEOS app.
Go to the Apple App Store, Google Play or Amazon App Store and search for "HEOS" to download and install.



- 2 Launch the HEOS app and follow the instructions in the app to add the Denon Home Subwoofer to your network and then group your Denon Home Subwoofer with the desired Denon Home speaker.



STEP 5: ADD SPEAKER



ENJOY!

OWNER'S MANUAL

- Refer to the online manual to learn more about product features and get the most out of your new subwoofer. manuals.denon.com/DenonHomeSubwoofer/EU/EN/
- For more information, visit www.denon.com



BASIC TROUBLESHOOTING

My subwoofer won't connect to my network

- Make sure your mobile device is connected to your wireless network before setting up your subwoofer.
- Alternately, you can connect your subwoofer to your network router using an Ethernet cable (not included). Once connected via Ethernet, the HEOS app should recognize the subwoofer and then you can manually connect it to your wireless network. To connect it to your wireless network, select **Settings > My Devices > [Device Name] > Advanced > NETWORK SETTINGS**.

Connecting to a network using WPS

- If your wireless router supports WPS (Wi-Fi Protected Setup™), you can connect the subwoofer to your network using the “Push Button” method as follows:
 1. Press the WPS button on your router.
 2. Within 2 minutes, press and hold the CONNECT button on the rear panel of the subwoofer for 5 seconds.
 3. The light on the front of the subwoofer will flash green for several seconds as it connects to your router.
 4. When the connection is complete, the light on the front of the subwoofer will turn solid blue.

Resetting your subwoofer

- Resetting your subwoofer will erase the wireless network settings and name but retain the current software.
- To reset your subwoofer, press and hold the RESET button on the rear panel of the subwoofer for 5 seconds until the front light begins to flash amber.
- After the reset process, you must reconnect the subwoofer to your home network. To reconnect, select **Settings > Add Device** in the HEOS app.

The HEOS app and brand is not affiliated with any manufacturer of any mobile device.

HEOS and the HEOS logo are trademarks or registered trademarks in the US and/or other countries.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google Play is a trademark of Google Inc.

Amazon, Kindle, Echo, Alexa, Dash, Fire and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

The Wi-Fi Protected Setup™ logo is a trademark of Wi-Fi Alliance.

All other trademarks are the property of their respective owners.

CONTACT Denon

 **00800-43674357**

EN

FREE HELPLINE

We hope you will enjoy your Denon product for years to come. If you ever have any questions or need any support, just get in touch. We are happy if you are happy.

The free HEOS helpline (English) is currently available in the United Kingdom, Ireland, Sweden, Norway, Denmark and Finland.

For more information visit www.denon.eu/support

ES

TELÉFONO GRATUITO DE AYUDA (DISPONIBLE EN ESPAÑA)

Encontrarás las respuestas a las preguntas más frecuentes y más información en

www.denon.eu/support

NL

GRATIS HULPLIJN

We hopen dat u jarenlang zult genieten van uw Denon-product. Als u vragen heeft of ondersteuning nodig heeft, neem dan gewoon contact op. Als jij blij bent, zijn wij dat ook.

Hulplijn is beschikbaar in Nederland, België en Luxemburg.

Meer informatie is te vinden op www.denon.eu/support

PL

BEZPŁATNA INFOLINIA (DOSTĘPNA W POLSKA)

Odpowiedzi na najczęściej zadawane pytania i bardziej przydatne informacje można znaleźć pod adresem

www.denon.eu/support

DE

KOSTENFREIER SUPPORT

Wir hoffen, Sie werden viele Jahre lang Vergnügen an Ihrem Denon-Produkt haben. Falls Sie zu irgendeinem Zeitpunkt Fragen haben oder Unterstützung benötigen, zögern Sie nicht, uns zu kontaktieren.

Die kostenfreie Rufnummer für den deutschsprachigen Support steht Ihnen in Deutschland, Österreich und der Schweiz zur Verfügung.

Weitere Informationen erhalten Sie unter www.denon.eu/support

OTHER REGIONS / AUTRES PAYS

For support options in other countries than those mentioned above, please visit www.denon.eu and choose your country.

Pour connaître les options de support dans d'autres pays, par avance merci de vous connecter dans notre site www.denon.eu puis sélectionner votre pays.

DENON[®]

www.denon.com

Printed in Vietnam 5411 11937 30AS
©2021 Sound United. All Rights Reserved.